


Molded Case Circuit Breakers and Switches

Shunt Trips for Type NZM10-...-NA

Rated Actuating Voltage U_s	Type Suffix	Price	Type	Price
V	Article No. when ordered with basic device	see price list	Article No. when ordered separately ¹⁾	see price list
Shunt trips Typically used to electrically trip the device from a remote location. Rated for 100% continuous duty. Shunt trips cannot be mounted together with undervoltage trips.				
				
AC/DC	24	+A-NZM10(24V) 036641	A-NZM10(24V) 036642	
	48	+A-NZM10(48V) 036643	A-NZM10(48V) 036644	
	60	+A-NZM10(60V) 036645	A-NZM10(60V) 036646	
	110 – 120	+A-NZM10(110-120V) 036647	A-NZM10(110-120V) 036648	
	125 – 130	+A-NZM10(125-130V) 036649	A-NZM10(125-130V) 036650	
	208 – 215	+A-NZM10(208-215V) 036651	A-NZM10(208-215V) 036652	
	220 – 240	+A-NZM10(220-240V) 036653	A-NZM10(220-240V) 036654	
	380 – 415	+A-NZM10(380-415V) 036655	A-NZM10(380-415V) 036656	
	440 – 480	+A-NZM10(440-480V) 036657	A-NZM10(440-480V) 036658	
	500	+A-NZM10(500V) 036659	A-NZM10(500V) 036660	
	600	+A-NZM10(600V) 036661	A-NZM10(600V) 036662	

Notes

¹⁾ Shunt trips are field installable.